




Freeze Prevention Procedures for Indoor PVB's



PVB Freeze Prevention Procedures:

1. Go to control clock and start manual cycle.
2. Close Valve "A".
3. After control clock has completed manual cycle, turn controller to off position.
4. Close Valve "B".

Only a complete winterization by Lipetzky's Irrigation can prevent your entire system from freeze damage.